



# LOCKING CASTERS - INSTRUCTIONS

## OVERVIEW:

These instructions are for attaching casters to your Boltz product. If you have any questions about this, please contact customer service at 877.804.7650.

Start by setting your base upside down so that the holes for the casters are facing upwards. Use caution not to scratch your finish or the work surface.



**STEP 1.** Slide the washer and then the copper jacket over the dome bolt.



**STEP 2.** Insert the bolt through the bottom of the caster so that the threads are coming out of the top.



**STEP 3 .** With the bolt inserted through the caster, put the threads through the hole in the base Attach the hex nut onto the bolt and hand tighten.



**STEP 4 .** Use the allen wrench to tighten the bolt while holding the nut with the Boltz Wrench. **Tighten completely.** Repeat for each caster.



### Parts List

- 1. Boltz Wrench
- 2. Allen Wrench
- 3. Flange Nut
- 4. Copper Jacket
- 5. Washer
- 6. Dome Bolt
- 7. Caster

NOTE: Extra pieces may be included.